

Painting PVC-U Window & Door Frames

Start by cleaning the PVC-U with a cream cleaner (such as Cif) to remove any green, grease or dirt from the windows.

Clean the windows with warm water to remove the cleaning product.

Lightly abrade with a fine grade scouring pad.

Clean off with methylated spirit.

Apply one coat of Fenwick & Tilbrook Multi-surface Primer.

Finish with two coats of Fenwick & Tilbrook Exterior Eggshell.

Light sanding between coats will aid adhesion.

Once painted, give the surface time to cure. Full curing of the paint can take between four and seven days, depending upon drying conditions.